


OPERATING INSTRUCTIONS

CHRONOGRAPHS WITH CALIBER ETA VALJOUX 7750



1 Crown

If necessary, pull out or unscrew the crown (if the crown is screwed-down) by turning counter-clockwise (towards yourself)

Position 1 allows manual winding of the timepiece by turning the crown clockwise (away from yourself)

Position 2: adjusts day/date by winding clockwise or counter-clockwise

DO NOT ADJUST THE DATE BETWEEN 9PM AND 3 AM. IT MAY DAMAGE THE DATE MECHANISM.

Position 3: adjusts the time

2 Hour hand

3 Minute hand

4 Running seconds

5 Chronograph Start/Stop

Press this button once to start the chronograph seconds hand.

Press this button again to stop the chronograph seconds hand

6 Chronograph Reset

After stopping the chronograph, press this button to reset the chronograph registers back to zero. This button will not work if the chronograph is still active.

7 Chronograph seconds hand

When the chronograph is activated the central chronograph hand will rotate once around the dial every 60 seconds.

8 Chronograph 30-minute counter

After each 60-second rotation of the chronograph seconds hand, this counter will register an additional minute up to 30 minutes.

9 Chronograph 12-hour counter

This counter registers each half hour of chronograph elapsed time up to 12 hours.

10 Date Window

11 Day-of-the-week Window

12 Tachymeter

Used to measure average velocity over a measured mile/kilometer. Start the chronograph at the beginning of the measured mi/km. Stop the chronograph at 1mi/1km. Read off the average velocity.